

### DOOR

1. Locate the correct door by looking at the mark or opening number on the door label.
2. Unpack the door.
3. Verify the door with the drawing and hardware schedule to ensure that you have the correct door, frame, and hardware set.
4. Before starting door installation, make sure the frame opening is the correct width and is plumb, square, and level. If the opening is not true, it can cause issues with the door fit as well as hardware function.
5. Locate the top of the door by comparing the hinge locations on the frame to the hinge locations on the door.
6. Check the screw holes and reinforcements in the door and frame to make sure they are clear of foreign matter.
7. Stand up the door and move it close to the opening
8. Place a wood wedge or other support under the door to hold the weight
9. Align the top hinge on the door with the top hinge cutout on the frame. The top hinge is typically installed first to hold the weight of the door.
10. Using the screws, install the hinges to the frame reinforcement at the top hinge location.
11. Install the middle and bottom hinge.
12. Remove the wood wedge or other support from under the door.
13. Close the door and verify there are proper clearances between the rabbet of the frame and the edge of the door. The door should swing freely
14. Install lockset, closer, and any other auxiliary hardware.
15. After installing the lockset, open and close the door to ensure the latch is engaging properly in the strike.